Solarwatt Inverter & Battery Configuration Guide - AU

Each inverter model has a minimum or maximum allowed battery connection.
Please use the table below for reference.

	Single Phase	Three Phase
Inverter / Battery	Inverter vision one 1.1 (7 kW) Inverter vision one 1.1 (8kW) Inverter vision one 1.1 (9 kW) Inverter vision one 1.1 (9.9 kW) Inverter vision one 1.1 (10 kW) Inverter vision one 1.1 (10.5 kW)	Inverter vision three 1.1 (5.0 kW) Inverter vision three 1.1 (6.0 kW) Inverter vision three 1.1 (8.0 kW) Inverter vision three 1.1 (9.9 kW) Inverter vision three 1.1 (10.0 kW) Inverter vision three 1.1 (15.0 kW)
SOLARWATT Battery vision	Battery vision two 2.1 Battery vision three 2.1 Battery vision four 2.1 Battery vision five 2.1 Battery vision six 2.1	Battery vision two 2.1 Battery vision three 2.1 Battery vision four 2.1 Battery vision five 2.1 Battery vision six 2.1

Black Start: Starting inverter without PV or Grid, only with battery.
Black Start Condition: Battery operating voltage should be higher than the minimum inverter battery operating voltage requirement, otherwise the Black Start function cannot be activated.

Dresden, 09.11.2026



Peter Bachmann
Chief Product Officer (CPO)

Solarwatt GmbH
Maria-Reiche-Str. 2a
01109 Dresden
solarwatt.de

2026 Solarwatt GmbH