


How to invite an Installer to Join Agent Organization

Inviting an Installer to Join Your Organization (For Admins)


Step 1 Log into FoxCloud2.0 APP

- Navigate to “Me” page and click “Invite Code” .




Step 2 Generate invitation code

- Select “Installer Invite Code” and click “Generate Code” .




Step 3 Finish

- After confirming notice, click “Copy & Close” to share the code. Then you can send it to installers.



Edit Plant Information

Step 1 Click 'Edit Plant'



Step 2 Switch Agent, and then confirm.

Basic

* Plant Name

2CT

* Currency

AUD(\$)

* Agent

join usw

Plant Profile Image



Address

Search a Location

Please select a location.

* Country / Region Country / Region

Australia

* City

Melbourne

* Detailed Address

Melbourne

* ZIP / Postal code