


1

WiFi Stick Installation

Alarm: The datalogger can only be plugged into the inverter, not any other device.

Step 1:

Rotate the lock, make sure the triangle mark is on the front and centered. Plug the Smart WiFi into WiFi/GPRS port under the bottom (underside) of the inverter. Tighten the nut clockwise as following.



Step 2:

Power on the inverter (in accordance with the start-up procedure detailed in the inverter installation manual).

Note:

1. For Brasil: Regulamento Anatel sobre equipamentos de Radiocomunicação de Radiação Restrita (Resolução nº 680): "Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados".
2. Warning: This is a class A Product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
3. Products exported to Brasil have obtained ANATEL certification, and the following signs will be placed on the shell.



For detailed profile information, please scan the QR code below.



Note: Contains app download path, configuration process, etc.

